

## Instructions



### HB125 Heater Base

Place Object on Top



#### Each Heater Base Contains

- 125 watt, 110 volt heating element
- Eight foot, 3 prong grounded cord
- Thermostat control turns on and off automatically for economical operation

\*Fully assembled and ready to use

#### Setup

- Place unit on flat surface
- Plug it into GFCI outlet
- Place metal fount, bowl or pan on top of unit

#### \*IMPORTANT\*

- Designed to heat metal founts, bowls and pans only
- For outdoor use in a dry, sheltered area
- Cord should be protected from animal and used with GFCI outlet

#### CAUTION

MAKE SURE TO FOLLOW ALL INSTRUCTIONS BEFORE USING THIS PRODUCT.

To help prevent electric shock

1. Have a qualified electrician install a GFCI outlet that meets local and national electrical codes
2. Route the supply cord and locate the heater so as to be protected from damage by animals
3. Do not use extension cords
4. Inspect cord before using
5. Unplug heater at GFCI outlet when not in use
6. Store heater base indoors when not in use
7. Keep out of reach of children

## Instructions



### HB125 Heater Base

Place Object on Top



#### Each Heater Base Contains

- 125 watt, 110 volt heating element
- Eight foot, 3 prong grounded cord
- Thermostat control turns on and off automatically for economical operation

\*Fully assembled and ready to use

#### Setup

- Place unit on flat surface
- Plug it into GFCI outlet
- Place metal fount, bowl or pan on top of unit

#### \*IMPORTANT\*

- Designed to heat metal founts, bowls and pans only
- For outdoor use in a dry, sheltered area
- Cord should be protected from animal and used with GFCI outlet

#### CAUTION

MAKE SURE TO FOLLOW ALL INSTRUCTIONS BEFORE USING THIS PRODUCT.

To help prevent electric shock

1. Have a qualified electrician install a GFCI outlet that meets local and national electrical codes
2. Route the supply cord and locate the heater so as to be protected from damage by animals
3. Do not use extension cords
4. Inspect cord before using
5. Unplug heater at GFCI outlet when not in use
6. Store heater base indoors when not in use
7. Keep out of reach of children